


Grandstream GXP 2130 User Guide



Voicemail
 Default password is 7777
 To setup custom voicemail greetings please press "0"
 and follow the instructions.

Blind Transfer.
 During the first active call, press TRANSFER and dial the number to transfer to;
 Press SEND key or # to complete transfer of active call.

Attended Transfer.
 During the first active call, press LINE key. The first call will be put on hold;
 Enter the number for the second call in the new line and establish the call;
 Press TRANSFER;
 Press the other LINE key which is on hold to transfer the call.

Initiate Conference
 Establish calls with 2 or more parties respectively;
 While 1 call is active, the other call will be put on hold with its LINE key blinking in green;
 Press CONF key;
 Press the desired LINE key on hold, the conference will be established;
 Repeat the previous 2 steps for all the other parties on hold to join the conference.

Pickup
 To answer the call ringing on another extension;
 Press Pickup (For multi phones only)

Outgoing caller ID:

- Simply enter the number and press dial.

